







Mac Printing




Mailbox and Secured Print

Mac Printing






Printing to the Mailbox

- Select **Special Features** from the drop-down menu.
- Select **Store**.




Printing to the Mailbox

- A dialogue box will appear.
- Enter Data Name and select your box number.





Mailbox at Your MFD (Multifunctional Device)



- To edit your mailbox, press the **Additional Functions** button to the right of the LCD screen.
- Press **Mailbox Settings**.
- Press **Box Set/Store**.
- Find your mail box and edit settings (i.e. name, password, time).

Printing with a Password – Secured Print

- Select **Special Features** from the drop-down menu.
- Select **Secured Print**.



Printing to Secured Print

Secured Print



Document will be printed in the Secured Print mode.
Set document name, user name, and password.
If you change the user name, jobs cannot be deleted with Print Monitor.


Document Name: (Max. 32 characters)
User Name: Mac User (Max. 32 characters)
Password: (0 to 99999999)

Cancel


OK



Secured Print at Your MFD




System Monitor



Secured Print at Your MFD

- Select **Print** from the list at the bottom of the screen.
- Select **Status**.
- Find your document and press **Secured Print**.



Secured Print at Your MFD

- When prompted, enter your **Password**, using the numeric key pad.
- The document is erased after printing .

